



Dart Aerospace Ltd.
1270 Aberdeen St
Hawkesbury, ON
K6A 1K7
Canada

Tel (613) 632-5200

D350-591-311
Job Sheet 178936



Part No: D350-591-311

Job Qty: 3 ea

Part Name: Heli-Access-Step™ LH - High Gear, Long Step, Aerazur Float Compatible



Part Weight: 0 lbs

Status: Scheduled

Priority: Medium

Job Created: 6/11/18

Job Tracking No:

Due Date: 7/6/18

Created By: Marie Lajeunesse

Type: SOLD

Description:

Note: DWG REV B IPP Rev:A 04.03.22 New issue KJ/RF IPP Rev:B 07-06-09 Added D3272-1 JLM IPP C returned to CHG001 for Eurocopter, ref NCR08-082 LL verified by:EC IPP Rev:D fixe route seq in bom DD 10.04.28 verified by:EC

Ship Via:

Non-Airbus

5083126 - 3219
5069554 - 3067
5046116 - 3272

Bill of Materials

Job Routing

Op No	Operation	Qty	Start Date	Due Date	Standard		Workcenter/Supplier		Sign-off
					Setup hrs	Run Hrs	Workcenter / Supplier	Lead Time	
90	Start up Operation	3 Ea	7/6/18	7/6/18	0.00	0.00	Start Up Large Fab-4		<i>SLK</i>
110	Large Fab	3 pcs	7/6/18	7/6/18	0.00	2.97	Large Fab 2		<i>CPC</i>
120	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC9		<i>SLK</i>
130	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC5		<i>SLK</i>
140	HandFinish	3 pcs	7/6/18	7/6/18	0.00	0.55	HandFinish1		<i>SA 18-07-24</i>
150	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC7-2		<i>CPC</i>
180	Large Fab	3 pcs	7/6/18	7/6/18	0.00	2.97	Large Fab 2		<i>CPC</i>
190	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC10		<i>SLK</i>
200	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC5		<i>SLK</i>
210	HandFinish	3 pcs	7/6/18	7/6/18	0.00	0.55	HandFinish1		<i>SA 18-07-30</i>
220	Powdercoat	3 pcs	7/6/18	7/6/18	0.00	0.87	Powdercoat1		<i>W 18-7-31</i>
230	HandFinish	3 pcs	7/6/18	7/6/18	0.00	0.55	HandFinish3		<i>KE 18-07-31</i>
240	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC3		<i>PD 18-08-01</i>
250	Packaging	3 pcs	7/6/18	7/6/18	0.00	0.00	Packaging1-3		<i>AUG 24 2018</i>
260	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC4		<i>6 08 09</i>
270	Packaging	3 pcs	7/6/18	7/6/18	0.00	0.00	Packaging3-1		<i>6 08 09</i>
275	DC	3 pcs	7/6/18	7/6/18	0.00	0.00	DC		<i>21 08 09</i>
280	QC21-FG	3 Ea	7/6/18	7/6/18	0.00	0.00	QC21		<i>21 08 09</i>

Part Op 110 - 1-Bevel end for welding FWD ONLY 2-Weld Support using Jig DT8719, weld Fwd End Plate as per QSI 004 & Dwg Descriptions: D3272 A/R Aluminum Rod *M134785* 3-Grind End Plate flush

180 - 1-Assemble Leg Assembly as per Dwg D3272. 2-Leave one rivet out until welding is complete. 3-Bevel Aft end for welding 4-Inspect for foreign object as per QSI 024 5-Weld Aft End Plate as per QSI 004 & Dwg D3272 A/R Aluminum Rod *M134785* 6-Grind End Plate flush 7-Install last rivet as per Dwg.

220 - START TIME: *7:30am* OVEN TEMPERATURE: *320°C* FINISH TIME: *8:00am*

270 - Identify and pack for shipping as per PPPD350-591-311 Location : FG084

275 - Photocopy bluefile and type labels as per PPP D350-591-311 CHG001

wing walk. M138851

004662

Job BOM

Part / Item	Component Name	Quantity	Operation	Container
D3067-1	End Plate	6 Ea (2 ea)	90-Start up Operation	<i>5069554</i>
D3219-1	Plate	6 Ea (2 ea)	90-Start up Operation	<i>5083126</i>
D3272-1	Step	3 Ea (1 ea)	90-Start up Operation	<i>5091615</i>
D3065-041	Step Leg Assembly	3 Ea (1 ea)	180-Large Fab	

DQA: _____ Date: _____



WORK ORDER NON-CONFORMANCE / UPDATE

QA Closed: _____ Date: _____

Work Order update only ☐

Work Order: _____ Part No. _____ NCR No. _____	DISPOSITION Rework ☐ Scrap ☐ Use-as-is ☐ Suspected Unapproved ☐	AGAINST DEPARTMENT/PROCESS <table style="width:100%; border: none;"> <tr> <td style="border: none;">Skid-tube ☐</td> <td style="border: none;">Cross tube ☐</td> <td style="border: none;">Water Jet ☐</td> <td style="border: none;">Engineering ☐</td> </tr> <tr> <td style="border: none;">Machining ☐</td> <td style="border: none;">Small Fab ☐</td> <td style="border: none;">Prod. Eng. Coord. ☐</td> <td style="border: none;">Quality ☐</td> </tr> <tr> <td style="border: none;">Thermoforming ☐</td> <td style="border: none;">Finishing ☐</td> <td style="border: none;">Rec/Store/Packaging ☐</td> <td style="border: none;">Other ☐</td> </tr> <tr> <td style="border: none;">Large Fab ☐</td> <td style="border: none;">Composite ☐</td> <td style="border: none;">Supplier ☐</td> <td></td> </tr> </table>				Skid-tube ☐	Cross tube ☐	Water Jet ☐	Engineering ☐	Machining ☐	Small Fab ☐	Prod. Eng. Coord. ☐	Quality ☐	Thermoforming ☐	Finishing ☐	Rec/Store/Packaging ☐	Other ☐	Large Fab ☐	Composite ☐	Supplier ☐																																																
Skid-tube ☐	Cross tube ☐	Water Jet ☐	Engineering ☐																																																																	
Machining ☐	Small Fab ☐	Prod. Eng. Coord. ☐	Quality ☐																																																																	
Thermoforming ☐	Finishing ☐	Rec/Store/Packaging ☐	Other ☐																																																																	
Large Fab ☐	Composite ☐	Supplier ☐																																																																		
Date : _____	Step #: _____	QTY Effective : _____		MRB (QSI042) Approval																																																																
Description Work Order Deviation		Disposition		Completed By																																																																
				Lead hand / Supervisor Approval Verification																																																																
				QC / QA Coordinator Approval																																																																
Root Cause <table style="width:100%; border: none;"> <tr><td style="border: none;">Environment ☐</td><td style="border: none;">No Re-verification ☐</td></tr> <tr><td style="border: none;">Design ☐</td><td style="border: none;">Operator ☐</td></tr> <tr><td style="border: none;">Doc/Data ☐</td><td style="border: none;">Offset/Setup ☐</td></tr> <tr><td style="border: none;">Equip/Tooling ☐</td><td style="border: none;">Supplier ☐</td></tr> <tr><td style="border: none;">Handling/Pre ☐</td><td style="border: none;">Training ☐</td></tr> <tr><td style="border: none;">Material ☐</td><td style="border: none;">Use for Testing ☐</td></tr> <tr><td style="border: none;">Internal Transport ☐</td><td style="border: none;">Poor Information ☐</td></tr> <tr><td style="border: none;">Tribal Knowledge ☐</td><td style="border: none;">Rushing ☐</td></tr> <tr><td style="border: none;">LOA ☐</td><td style="border: none;">Product Improvement ☐</td></tr> <tr><td style="border: none;">Substation ☐</td><td style="border: none;">Process Improvement ☐</td></tr> <tr><td style="border: none;">Past Expiry Date ☐</td><td style="border: none;">Manufacturing Process ☐</td></tr> <tr><td style="border: none;">Misidentified ☐</td><td style="border: none;">Past Due ☐</td></tr> </table>		Environment ☐	No Re-verification ☐	Design ☐	Operator ☐	Doc/Data ☐	Offset/Setup ☐	Equip/Tooling ☐	Supplier ☐	Handling/Pre ☐	Training ☐	Material ☐	Use for Testing ☐	Internal Transport ☐	Poor Information ☐	Tribal Knowledge ☐	Rushing ☐	LOA ☐	Product Improvement ☐	Substation ☐	Process Improvement ☐	Past Expiry Date ☐	Manufacturing Process ☐	Misidentified ☐	Past Due ☐	FAULT CATEGORY <table style="width:100%; border: none;"> <tr><td style="border: none;">Pressure/Forced ☐</td><td style="border: none;">Temperature/Cure ☐</td><td style="border: none;">Power Loss/Surge ☐</td><td style="border: none;">Positioned Wrong ☐</td></tr> <tr><td style="border: none;">Bending ☐</td><td style="border: none;">Set-up ☐</td><td style="border: none;">Folio/Program ☐</td><td style="border: none;">Outside Dimensions ☐</td></tr> <tr><td style="border: none;">Centre Not Concentric ☐</td><td style="border: none;">BOM/Route ☐</td><td style="border: none;">Grain ☐</td><td style="border: none;">Over/Under tolerance ☐</td></tr> <tr><td style="border: none;">Cracks ☐</td><td style="border: none;">Broken/Damage/Defect ☐</td><td style="border: none;">Weld ☐</td><td style="border: none;">Part Incorrect ☐</td></tr> <tr><td style="border: none;">Crimp/Kink/Ripple/Wave ☐</td><td style="border: none;">Inspection Incomplete/Unqualified ☐</td><td style="border: none;">Wrong Stock Pulled ☐</td><td style="border: none;">Part Lost/Missing ☐</td></tr> <tr><td style="border: none;">Cuffs ☐</td><td style="border: none;">Contamination ☐</td><td style="border: none;">Out of Sequence ☐</td><td style="border: none;">Part Moved ☐</td></tr> <tr><td style="border: none;">Crushing ☐</td><td style="border: none;">Countersink ☐</td><td style="border: none;">Off-set ☐</td><td style="border: none;">Drawing ☐</td></tr> <tr><td style="border: none;">Heat Treat ☐</td><td style="border: none;">Cut Too Short ☐</td><td style="border: none;">Mislabeled ☐</td><td style="border: none;">Finish ☐</td></tr> <tr><td style="border: none;">Wave/Twist in Tube ☐</td><td style="border: none;">Instructions Incomplete/Unclear ☐</td><td style="border: none;">Fit/Function ☐</td><td style="border: none;">Misread ☐</td></tr> <tr><td style="border: none;">Marks/Chatter ☐</td><td style="border: none;">Drill Holes ☐</td><td style="border: none;">Misaligned/off center ☐</td><td style="border: none;">Turning Sequence ☐</td></tr> </table>			Pressure/Forced ☐	Temperature/Cure ☐	Power Loss/Surge ☐	Positioned Wrong ☐	Bending ☐	Set-up ☐	Folio/Program ☐	Outside Dimensions ☐	Centre Not Concentric ☐	BOM/Route ☐	Grain ☐	Over/Under tolerance ☐	Cracks ☐	Broken/Damage/Defect ☐	Weld ☐	Part Incorrect ☐	Crimp/Kink/Ripple/Wave ☐	Inspection Incomplete/Unqualified ☐	Wrong Stock Pulled ☐	Part Lost/Missing ☐	Cuffs ☐	Contamination ☐	Out of Sequence ☐	Part Moved ☐	Crushing ☐	Countersink ☐	Off-set ☐	Drawing ☐	Heat Treat ☐	Cut Too Short ☐	Mislabeled ☐	Finish ☐	Wave/Twist in Tube ☐	Instructions Incomplete/Unclear ☐	Fit/Function ☐	Misread ☐	Marks/Chatter ☐	Drill Holes ☐	Misaligned/off center ☐	Turning Sequence ☐
Environment ☐	No Re-verification ☐																																																																			
Design ☐	Operator ☐																																																																			
Doc/Data ☐	Offset/Setup ☐																																																																			
Equip/Tooling ☐	Supplier ☐																																																																			
Handling/Pre ☐	Training ☐																																																																			
Material ☐	Use for Testing ☐																																																																			
Internal Transport ☐	Poor Information ☐																																																																			
Tribal Knowledge ☐	Rushing ☐																																																																			
LOA ☐	Product Improvement ☐																																																																			
Substation ☐	Process Improvement ☐																																																																			
Past Expiry Date ☐	Manufacturing Process ☐																																																																			
Misidentified ☐	Past Due ☐																																																																			
Pressure/Forced ☐	Temperature/Cure ☐	Power Loss/Surge ☐	Positioned Wrong ☐																																																																	
Bending ☐	Set-up ☐	Folio/Program ☐	Outside Dimensions ☐																																																																	
Centre Not Concentric ☐	BOM/Route ☐	Grain ☐	Over/Under tolerance ☐																																																																	
Cracks ☐	Broken/Damage/Defect ☐	Weld ☐	Part Incorrect ☐																																																																	
Crimp/Kink/Ripple/Wave ☐	Inspection Incomplete/Unqualified ☐	Wrong Stock Pulled ☐	Part Lost/Missing ☐																																																																	
Cuffs ☐	Contamination ☐	Out of Sequence ☐	Part Moved ☐																																																																	
Crushing ☐	Countersink ☐	Off-set ☐	Drawing ☐																																																																	
Heat Treat ☐	Cut Too Short ☐	Mislabeled ☐	Finish ☐																																																																	
Wave/Twist in Tube ☐	Instructions Incomplete/Unclear ☐	Fit/Function ☐	Misread ☐																																																																	
Marks/Chatter ☐	Drill Holes ☐	Misaligned/off center ☐	Turning Sequence ☐																																																																	
OTHER : _____																																																																				

D3066-1	Spacer	6 Ea (2 ea)	180-Large Fab
MS20600-AD4W4	Rivet	48 Ea (16 ea)	180-Large Fab
AN3-35A	Bolt	6 Ea (2 ea)	250-Packaging
AN4-13A	Bolt	24 Ea (8 ea)	250-Packaging
AN5-36A	Bolt	6 Ea (2 ea)	250-Packaging
D2230-3	Mounting Lug	12 Ea (4 ea)	250-Packaging
D2618	Bushing	6 Ea (2 ea)	250-Packaging
D2856-400-720	Abrasion Strip 4" X 7.20"	6 Ea (2 ea)	250-Packaging
D3235-1	Mounting Lug	6 Ea (2 ea)	250-Packaging
D3278-041	Support Assembly	3 Ea (1 ea)	250-Packaging
MS21042L3	Nut	6 Ea (2 ea)	250-Packaging
MS21042L4	Nut	24 Ea (8 ea)	250-Packaging
MS21042L5	Nut	6 Ea (2 ea)	250-Packaging
NAS1149D0363J	Washer	12 Ea (4 ea)	250-Packaging
NAS1149D0463J	Washer	48 Ea (16 ea)	250-Packaging
NAS1149D0563J	Washer	12 Ea (4 ea)	250-Packaging

Job Allocations

Operation	Component Part	Required	Inventory	Allocated
90-Start up Operation	D3067-1	6	256	0
	D3219-1	6	155	0
	D3272-1	3	10	0
180-Large Fab	D3065-041	3	10	0
	D3066-1	6	229	0
	MS20600-AD4W4	48	3,996	0
250-Packaging	AN3-35A	6	308	0
	AN4-13A	24	1,193	0
	AN5-36A	6	302	0
	D2230-3	12	20	0
	D2618	6	148	0
	D2856-400-720	6	156	0
	D3235-1	6	246	0
	D3278-041	3	46	0
	MS21042L3	6	1,881	0
	MS21042L4	24	2,959	0
	MS21042L5	6	651	0
	NAS1149D0363J	12	2,225	0
	NAS1149D0463J	48	5,122	0
	NAS1149D0563J	12	2,091	0

DST 9410 061 (1 each)

Part Specifications

Specifications could not be found.

Plex 6/11/18 10:39 AM Dart.lajeunesse.marie



DART Aerospace Ltd.
1270 Aberdeen Street
Hawkesbury, ON K6A 1K7
CANADA
TEL : 1 613 632-5200
Email: sales@dartaero.com
www.dartaerospace.com

Container No: S091882



Part: D350-591-311

Job No: 178936

Serial No/Batch: S091882

Revision:

Inspector:

Exp Date:

Instructions:

Date: 07/16/18

WORK ORDER NON-CONFORMANCE / UPDATE

QA Closed: _____ Date: _____

Wo

Work Order: _____	DISPOSITION		AGAINST DEP
Part No. _____	Rework ☐	Skid-tube ☐	Cross tube ☐
NCR No. _____	Scrap ☐	Machining ☐	Small Fab ☐
	Use-as-is ☐	Thermoforming ☐	Finishing ☐
	Suspected Unapproved ☐	Large Fab ☐	Composite ☐

Date :	Step #:	QTY Effective :
--------	---------	-----------------

[illegible]

QC / QA Coordinator
Approval

Root Cause			FAULT CATEGORY			
Environment		No Re-verification	Pressure/Forced	Temperature/Cure	Power Loss/Surge	Positioned Wrong
Design		Operator	Bending	Set-up	Folio/Program	Outside Dimensions
Doc/Data		Offset/Setup	Centre Not Concentric	BOM/Route	Grain	Over/Under tolerance
Equip/Tooling		Supplier	Cracks	Broken/Damage/Defect	Weld	Part Incorrect
Handling/Pre		Training	Crimp/Kink/Ripple/Wave	Inspection Incomplete/Unqualified	Wrong Stock Pulled	Part Lost/Missing
Material		Use for Testing	Cuffs	Contamination	Out of Sequence	Part Moved
Internal Transport		Poor Information	Crushing	Countersink	Off-set	Drawing
Tribal Knowledge		Rushing	Heat Treat	Cut Too Short	Mislabeled	Finish
LOA		Product Improvement	Wave/Twist in Tube	Instructions Incomplete/Unclear	Fit/Function	Misread
Substation		Process Improvement	Marks/Chatter	Drill Holes	Misaligned/off center	Turning Sequence
Past Expiry Date		Manufacturing Process				
Misidentified		Past Due	OTHER :			



Dart Aerospace Ltd.
1270 Aberdeen St
Hawkesbury, ON
K6A 1K7
Canada

Tel (613) 632-5200

D350-591-311
Job Sheet 178936



Part No: D350-591-311

Job Qty: 3 ea

Part Name: Heli-Access-Step™ LH - High Gear, Long Step, Aerazur Float Compatible



Part Weight: 0 lbs

Status: Scheduled

Priority: Medium

Job Created: 6/11/18

Job Tracking No:

Due Date: 7/6/18

Created By: Marie Lajeunesse

Type: SOLD

Description:

Note: DWG REV B IPP Rev:A 04.03.22 New issue KJ/RF IPP Rev:B 07-06-09 Added D3272-1 JLM IPP C returned to CHG001 for Eurocopter, ref NCR08-082 LL verified by:EC IPP Rev:D fixe route seq in bom DD 10.04.28 verified by:EC

Ship Via:

Non-Airbus

Bill of Materials

Job Routing

Op No	Operation	Qty	Start Date	Due Date	Standard		Workcenter/Supplier		Sign-off
					Setup hrs	Run Hrs	Workcenter / Supplier	Lead Time	
90	Start up Operation	3 Ea	7/6/18	7/6/18	0.00	0.00	Start Up Large Fab-4		
110	Large Fab	3 pcs	7/6/18	7/6/18	0.00	2.97	Large Fab 2		
120	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC9		
130	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC5		
140	HandFinish	3 pcs	7/6/18	7/6/18	0.00	0.55	HandFinish1		
150	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC7-2		
180	Large Fab	3 pcs	7/6/18	7/6/18	0.00	2.97	Large Fab 2		
190	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC10		
200	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC5		
210	HandFinish	3 pcs	7/6/18	7/6/18	0.00	0.55	HandFinish1		
220	Powdercoat	3 pcs	7/6/18	7/6/18	0.00	0.87	Powdercoat1		
230	HandFinish	3 pcs	7/6/18	7/6/18	0.00	0.55	HandFinish3		
240	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC3		
250	Packaging	3 pcs	7/6/18	7/6/18	0.00	0.00	Packaging1-3		
260	QC	3 pcs	7/6/18	7/6/18	0.00	0.00	QC4		
270	Packaging	3 pcs	7/6/18	7/6/18	0.00	0.00	Packaging3-1		
275	DC	3 pcs	7/6/18	7/6/18	0.00	0.00	DC		
280	QC21-FG	3 Ea	7/6/18	7/6/18	0.00	0.00	QC21		

Part Op 110 - 1-Bevel end for welding FWD ONLY 2-Weld Support using Jig DT8719, weld Fwd End Plate as per QSI 004 & Dwg Descriptions: D3272 A/R Aluminum Rod 3-Grind End Plate flush

180 - 1-Assemble Leg Assembly as per Dwg D3272. 2-Leave one rivet out until welding is complete. 3-Bevel Aft end for welding 4-Inspect for foreign object as per QSI 024 5-Weld Aft End Plate as per QSI 004 & Dwg D3272 A/R Aluminum Rod 6-Grind End Plate flush 7-Install last rivet as per Dwg.

220 - START TIME: 7:30 AM OVEN TEMPERATURE: 210°C FINISH TIME: 8:00 AM

270 - Identify and pack for shipping as per PPPD350-591-311 Location : FG084

275 - Photocopy bluefile and type labels as per PPP D350-591-311 CHG001

wing work. M138851

104662

Job BOM

Part / Item	Component Name	Quantity	Operation	Container
D3067-1	End Plate	6 Ea (2 ea)	90-Start up Operation	
D3219-1	Plate	6 Ea (2 ea)	90-Start up Operation	
D3272-1	Step	3 Ea (1 ea)	90-Start up Operation	
D3065-041	Step Leg Assembly	3 Ea (1 ea)	180-Large Fab	

004807

D3066-1	Spacer	6 Ea (2 ea)	180-Large Fab
MS20600-AD4W4	Rivet	48 Ea (16 ea)	180-Large Fab
AN3-35A	Bolt	6 Ea (2 ea)	250-Packaging
AN4-13A	Bolt	24 Ea (8 ea)	250-Packaging
AN5-36A	Bolt	6 Ea (2 ea)	250-Packaging
D2230-3	Mounting Lug	12 Ea (4 ea)	250-Packaging
D2618	Bushing	6 Ea (2 ea)	250-Packaging
D2856-400-720	Abrasion Strip 4" X 7.20"	6 Ea (2 ea)	250-Packaging
D3235-1	Mounting Lug	6 Ea (2 ea)	250-Packaging
D3278-041	Support Assembly	3 Ea (1 ea)	250-Packaging
MS21042L3	Nut	6 Ea (2 ea)	250-Packaging
MS21042L4	Nut	24 Ea (8 ea)	250-Packaging
MS21042L5	Nut	6 Ea (2 ea)	250-Packaging
NAS1149D0363J	Washer	12 Ea (4 ea)	250-Packaging
NAS1149D0463J	Washer	48 Ea (16 ea)	250-Packaging
NAS1149D0563J	Washer	12 Ea (4 ea)	250-Packaging

DSI 9410-011

3 (ea)

3

8089307.
5089302
3071345
5085103103
3082275
5092007
5089615
5092091
5089840
5089365
5058178
5068661
5089299
5093773
5088446

Job Allocations

Operation	Component Part	Required	Inventory	Allocated
90-Start up Operation	D3067-1	6	256	0
	D3219-1	6	155	0
	D3272-1	3	10	0
180-Large Fab	D3065-041	3	10	0
	D3066-1	6	229	0
250-Packaging	MS20600-AD4W4	48	3,996	0
	AN3-35A	6	308	0
	AN4-13A	24	1,193	0
	AN5-36A	6	302	0
	D2230-3	12	20	0
	D2618	6	148	0
	D2856-400-720	6	156	0
	D3235-1	6	246	0
	D3278-041	3	46	0
	MS21042L3	6	1,881	0
	MS21042L4	24	2,959	0
	MS21042L5	6	651	0
	NAS1149D0363J	12	2,225	0
	NAS1149D0463J	48	5,122	0
	NAS1149D0563J	12	2,091	0

DSI 9410-011 (1 each)

Part Specifications

Specifications could not be found.

Plex 6/11/18 10:39 AM Dart.lajeunesse.marie



Container No: S091882



Part: D350-591-311

Job No: 178936

Serial No/Batch: S091882

Revision:

Inspector:

Exp Date:

Instructions

Date: 07/16/18

DART Aerospace Ltd.
1270 Aberdeen Street
Hawkesbury, ON K6A 1K7
CANADA
TEL: 1 613 632-5200
Email: sales@dartaero.com
www.dartaerospace.com



Dart Aerospace Ltd.
1270 Aberdeen St
Hawkesbury, ON
K6A 1K7
Canada

Tel (613) 632-5200
Fax 613 632-5246

Container View (Active) - Master Unit Containers

Master Unit No	Container No	Part No	Part Name	From Container	Current Location	Quantity
004807	S098391	AN3-35A	Bolt	S089307	ST348	6
004807	S098390	AN4-13A	Bolt	S089302	OVER003	24
004807	S098389	AN5-36A	Bolt	S071345	ST336	6
004807	S098388	D2618	Bushing	S082275	ST008	6
004807	S098387	D2856-400-720	Abrasion Strip 4" X 7.20"	S092667	ST418	6
004807	S098386	D3235-1	Mounting Lug	S089615	ST522	6
004807	S098385	D3278-041	Support Assembly	S092091	ST522	3
004807	S098384	DSI 9410-011	Amends Installation Of D350-591-311/-312 Steps	S088446	FG123	3
004807	S098383	MS21042L3	Nut	S089340	ST303	6
004807	S098382	MS21042L4	Nut	S089365	ST303	24
004807	S098381	MS21042L5	Nut	S058178	ST303	6
004807	S098380	NAS1149D0363J	Washer	S068661	ST263	12
004807	S098379	NAS1149D0463J	Washer	S089299	ST263	48
004807	S098378	NAS1149D0563J	Washer	S093773	ST263	12

Note: Ad hoc query view of Part.dbo.Container where Container.Active = 1.

Plex 8/1/18 2:11 PM Dart.joly.jocelyne

D2230-1 Qty 12 S103723

Qty -213	Qty -214	Qty -215	Qty -216	Qty -311	Qty -312	Part Number	Description
X						D350-591-213	<i>Heli-Access-Step™</i> , Short Step – High Skid, LH
	X					D350-591-214	<i>Heli-Access-Step™</i> , Short Step – High Skid, RH
		X				D350-591-215	<i>Heli-Access-Step™</i> , Short Step – Low Skid, LH
			X			D350-591-216	<i>Heli-Access-Step™</i> , Short Step – Low Skid, RH
				X		D350-591-311	<i>Heli-Access-Step™</i> , Long Step – High Skid, LH
					X	D350-591-312	<i>Heli-Access-Step™</i> , Long Step – High Skid, RH
1						D3078-041	STEP ASSEMBLY (HIGH-SHORT, LH)
	1					D3078-042	STEP ASSEMBLY (HIGH-SHORT, RH)
		1				D3168-041	STEP ASSEMBLY (LOW-SHORT, LH)
			1			D3168-042	STEP ASSEMBLY (LOW-SHORT, RH)
				1		D3272-041	STEP ASSEMBLY (HIGH-LONG, LH)
					1	D3272-042	STEP ASSEMBLY (HIGH-LONG, RH)
2	2	2	2	4	4	D2230-3	MOUNTING LUG
2	2	2	2	2	2	D2618	BUSHING
4	4	4	4			D2732-030	CUSHION
				2	2	D2856-400-720	ABRASION STRIP
2	2	2	2	2	2	D3235-1	MOUNTING LUG
				1	1	D3278-041	SUPPORT ASSEMBLY
2	2	2	2	2	2	AN3-35A	BOLT
				8	8	AN4-13A	BOLT
4	4	4	4			AN4-15A	BOLT
2	2	2	2	2	2	AN5-36A	BOLT
4	4	4	4	4	4	NAS1149D0363J	WASHER (AN960JD10)
12	12	12	12	16	16	NAS1149D0463J	WASHER (AN960JD416)
4	4	4	4	4	4	NAS1149D0563J	WASHER (AN960JD516)
2	2	2	2	2	2	MS21042L3	NUT
6	6	6	6	8	8	MS21042L4	NUT
2	2	2	2	2	2	MS21042L5	NUT
				1	1	*DSI 9410-011	STEP MODIFICATION KIT

*DSI 9410-011 Step Modification Kits are provided with all D350-591-311 and D350-591-312 Steps. This kit is provided as an option for the installer and is therefore **NOT REQUIRED** to complete the installation of the D350-591-311 or D350-591-312 Steps. Refer to Figure 15 for installation of the DSI 9410-011 Kit.

REFERENCE ONLY

REFERENCE ONLY

REFERENCE ONLY